



Taha Kimia Tajhiz Co.



Ofite Co.

CGP-90 Cement Permeameter with DAQ Datasheet

Cement Testing/ Permeability Equipment
#



CEMENT TESTING EQUIPMENT

For over 30 years OFI Testing Equipment (OFITE) has provided instruments and reagents for testing drilling fluids, well cements, completion fluids, and wastewater. In addition to these product lines we also offer a range of instruments for core analysis. From our manufacturing facility in Houston, TX we provide customers all over the world with quality products and exceptional service.

Our cement product line includes innovative designs such as the Static Gel Strength Measurement Device (SGSM) which showcases our ability to develop new technology to meet customer and industry demands. We also offer Ultrasonic Cement Analyzers (UCA), Constant Speed Blenders, Automated HTHP Consistometers, and all other instruments required to evaluate cement properties according to API Specification 10.

As an independent manufacturer and supplier, OFITE has one priority, our customers.

OFI TESTING EQUIPMENT, INC.
11302 Steeplecrest Dr.
Houston, TX 77065
877.837.8683
www.ofite.com
© Copyright OFITE 2015



CGP-90 Cement Permeameter with DAQ

The Cement Permeameter is designed to measure the permeability of cement core specimens one inch in diameter and one inch in length. A core specimen is placed into a core sleeve, which is then inserted into the "Modified Hassler" style test cell. Nitrogen at a constant flow rate is forced through the core and the differential pressure across the core is measured. The flowrate is measured with calibrated flowmeters. Viscosity is easily determined by the use of nitrogen property tables. These variables are incorporated into Darcy's law to calculate cement sample permeability.



Features

- Data Acquisition and Control system with software included
- Modified Hassler cell accommodates cores of 1" length and 1" diameter
- Instrumentation gauge displays driving pressure
- All Hassler components are fabricated from 316 Stainless Steel
- Nitrogen test fluid
- Cement mold included (#120-85-003)

Technical Specifications and Requirements

- #120-87-DAS CGP-90 Cement Permeameter with DAQ

Requirements

- Compressed Air: 100 PSI (689.5 kPa)
- Gas Pressure: Standard Air, Carbon Dioxide, Nitrogen, or Oxygen up to 500 PSI (3.5 MPa)
- Electrical: 115 Volt or 230 Volt 50 or 60 Hz